AMD Direct ID

Deluxe Cart Assembly Instructions

Model # CART-SIZ32-DC , CART-SF432-DC / CART-SIZ40-DC

Step 1: Remove parts from the carton and remove all protective film prior to assembly. (2 people recommended for assembly)

Step 2: Tilt the cart backward, down onto a protective surface, attach the 2 pcs Locking Casters (#1A) to the front positions and 2 pcs Casters (#1B) to the rear positions using 4 pcs of 10x24 screws (H-1), 4 pcs of Flat Washers (H-2) 4 pcs of Lock Washers (H-3) per caster.

Step 3: Lean cart upright. Attach left and right Sides Shelves (#2) using 4 pcs 10x24 screws (H-1) per shelf.

Step 4: Attach the Drawer & Door Handles (#3) to Drawers and Front Door using 2 pcs of Handle Screws (H-4) for each handle.

Step 5: Finally, the barbecue is ready to be installed into the cart. Once installed, secure the barbecue head with 2 pcs 10x24 screws (H-1) through the holes that are on each side (underneath the grates inside bbq on right and left side toward front).

Note: Some adjustments may be needed to obtain proper placement or level positioning in the cart. Make sure to tighten all the screws with a screwdriver once the cart is level.

Note: The Propane tank is held in position by the tightening the Tank Bracket Screw.

| No. | Description | Qty. |
|-----|-------------------------|------|
| 1A | Locking Caster | 2 |
| 1B | Caster | 2 |
| 2 | Side Shelves | 2 |
| 3 | Drawer & Door Handle | 3 |
| H-1 | 10 x 24 Screw | 26 |
| H-2 | Flat Washer | 16 |
| H-3 | Lock Washer | 16 |
| H-4 | Handle Screw | 6 |

