

REFRIGERATOR RISER PLATFORM COMPATIBLE WITH MODELS **RFR-24S-A, RFR-24G, & RFR-24DR2-A**

IMPORTANT SAFETY INSTRUCTIONS

1. Set the refrigerator on top of the pedestal as shown. (For safety, we recommend having two people lift it.)
2. Raise the two rear legs approximately 1/2" to 5/8" to allow easier engagement with the anti-tilt bracket.
3. Align the rear legs with the bracket and slide the refrigerator until fully engaged.
4. Adjust the rear legs to the desired height.
5. Slide the refrigerator and pedestal into the enclosure opening.

