

## DELUXE CART ASSEMBLY INSTRUCTIONS

**MODELS: CART-SZR32-DC/40-DC • CART-TRL32-DC/40-DC**

**STEP 1:** Two people are recommended for this assembly. Remove all packaging materials and protective film from the cart surfaces. Residue from the protective film may be present and is normal. After removal, clean all stainless steel surfaces with an appropriate stainless steel cleaner.

**STEP 2:** Carefully lean the cart backward onto a protected surface. Attach the four casters using four screws per caster. Install the locking casters on the front positions.

**STEP 3:** Attach the grill to the cart using two screws, securing them through the designated holes on each side of the grill (circled in red).

**STEP 4:** Use a Phillips-head screwdriver to attach the handles to the cart using the provided screws.

